




BAC original spare parts

For lowest process operating costs




1. Fan and drive components
2. Water distribution components
3. Fill
4. Coil
5. Eliminators
6. Louvers
7. Controls (not shown)



To select your correct replacement part, contact your local BAC representative.
www.BaltimoreAircoil.co.za

1. Fans and drive

- Axial fans
- Centrifugal fans
- Fan shafts
- Bearings
- Motors
- Sheaves
- Belts
- Gear boxes
- Baltiguard system




2. Water distribution

- Nozzles
- Spray branches
- Spray pumps
- Strainers
- Make-up
- Pump piping
- Clean out port
- Sump sweeper piping



3. Fill

- BACount
- BACross
- Versacross fill
- Versapak
- FRP fill
- High temperature fill
- Cross fill blocks



4. Coils


- Standard coil
- Coil and casing
- Extended surface coils
- Plume abatement coils
- Dry finned coils
- Ice storage coils



5. Eliminators


- Blade type
- Cellular type
- Metal eliminators
- Cassette type
- Fill integrated type

BAC eliminators are Eurovent certified.



6. Louvers

- Combined inlet shields
- Framed combined inlet shields
- Louvers
- Adiabatic pre-cooler pads



7. Controls

- Basin heater package
- Electric water level control package
- Low-high level switch
- Adiabatic controls
- Vibration cut out switch
- Hybrid controls

