



# Sound attenuation

## Refrigerant condensers

### Engineering data

**Remark:** Do not use for construction. Refer to factory certified dimensions & weights. This page includes data current at time of publication, which should be reconfirmed at the time of purchase. In the interest of product improvement, specifications, weights and dimensions are subject to change without notice.

1. Dimensional drawings show standard (right hand) arrangement can be furnished by special order.
2. Coil connection locations are approximate. Dimensions should not be used for prefabrication on the connecting piping. All coil connections are beveled for welding.
3. Shipping/ operating weights indicated are for units without accessories such as sound attenuators, discharge hoods ect. Consult factory certified prints to obtain weight additions and the heaviest section to be lifted. Operating weight shown in tables is based on total unit weight of refrigerant operating charge and basin filled to overflow level.
4. The units will be delivered in 3 different pieces, upper, middle and lower section.

### Sound attenuation



1. Unit width; 2. Unit height; 3. Insulated plenum; 4. Intake attenuator.

